

INDEX

CS-80	SPECIFICATIONS	1
CS-80	PANEL LAYOUT	2
CS-80	CORDING GUIDE	3
KAS	Circuit Diagram	4
SH	Circuit Diagram	7
TKC	Circuit Diagram	9
TSB1	Circuit Diagram	11
TSB2	Circuit Diagram	13
KBC1 - 2	Circuit Diagram	15
TWS	Circuit Diagram	17
TRG1 - 2	Circuit Diagram	19
TRG3	Circuit Diagram	21
TRG4	Circuit Diagram	23
TRG5	Circuit Diagram	25
BA	Circuit Diagram	27
SUB	Circuit Diagram	29
T51	Circuit Diagram	31
T52	Circuit Diagram	33
T53	Circuit Diagram	35
T54	Circuit Diagram	37
R51 - 52	Circuit Diagram	39
M	Circuit Diagram	41
PRA	Circuit Diagram	53
OE1	Circuit Diagram	55
OE2	Circuit Diagram	57
SVU	Circuit Diagram	59
Power Supply NP0018Z	Circuit Diagram	61
Panel 1	Circuit Diagram	62
Panel 1	(MBK) Circuit Diagram	63
Panel 2	Circuit Diagram	64
Panel 2	(Tone Selector) Circuit Diagram	65
Panel 3	Circuit Diagram	66
Panel 5	(EJ, EXP, PFS) Circuit Diagram	67

SPECIFICATIONS

KEYBOARD

61 keys C1 ~ c4 (5 octaves)

TONE SELECTORS

Channel I

STRING 1
STRING 3
BRASS 1
FLUTE
ELECTRIC PIANO
CLAVICHORD 1
HARPSICHORD 1
ORGAN 1
GUITAR 1
FUNKY 1
FUNKY 3
MEMORY 1
MEMORY 3
PANEL

Channel II

STRING 2
STRING 4
BRASS 2
BRASS 3
BASS
CLAVICHORD 2
HARPSICHORD 2
ORGAN 2
GUITAR 2
FUNKY 2
FUNKY 4
MEMORY 2
MEMORY 4
PANEL

TONE SLIDE CONTROLS

VCO (Voltage Controlled Oscillator) Section

SPEED

PWM (Pulse Width Modulation)

PW (Pulse Width)

□ (Square Wave) Switch (On/Off)

∩ (Sawtooth Wave) Switch (On/Off)

NOISE

VCF (Voltage Controlled Filter) Section

HPF (High Pass Filter)

RES_H (Resonance High)

LPF (Low Pass Filter)

RES_L (Resonance High)

IL (Initial Level)

AL (Attack Level)

A (Attack Time)

D (Decay Time)

R (Release Time)

VCA (Voltage Controlled Oscillator) Section

VCF LEVEL

~ (Sine Wave)

A (Attack Time)

D (Decay Time)

S (Sustain Level)

R (Release Time)

LEVEL

TOUCH RESPONSE Section

INITIAL Controls

BRILLIANCE

LEVEL

AFTER Controls

BRILLIANCE

LEVEL

MEMORY BANKS (VCO, VCF, VCA, TOUCH RESPONSE)

Memory 1

Memory 2

Memory 3

Memory 4

EFFECT CONTROLS

RING MODULATOR

ATTACK TIME

DECAY TIME

DEPTH

SPEED

MODULATION

TOUCH RESPONSE

INITIAL Control

PITCH BEND

AFTER Controls

SUB. OSCILLATOR

SPEED

VCO

VCF

SUB. OSCILLATOR

FUNCTION Selector (∩, ∩, ∩, ∩ NOISE, EXTERNAL)

SPEED

VCO

VCF

VCA

SUSTAIN

Select Switch (I/II)

SUSTAIN Time

PORTAMENTO/GLISSANDO

Select Switch (PORTAMENTO/GLISSANDO)

PORTAMENTO/GLISSANDO Time

FINGER BOARD

RESONANCE

BRILLIANCE

KEYBOARD CONTROLS

BRILLIANCE

LOW

HIGH

LEVEL

LOW

HIGH

ORCHESTRA EFFECT

Voice Selector (ON/OFF)

TREMOLO

CHORUS

SPEED

DEPTH

FEET levers (Channels I & II)

(16', 8', 5-1/3', 4', 2-2/3', 2')

OTHER CONTROLS

PITCH (Coarse & Fine Controls)

DETUNE (Channel II only)

CH. I/CH. II MIX

Master VOLUME

FOOT CONTROLLER (Pedal)

EXTERNAL IN LEVEL

FOOT PEDAL Selectors

(EXP./EXP. & WAH)

FOOT SWITCH Selectors (On/Off)

SUSTAIN

PORTAMENTO/GLISSANDO

POWER SWITCH (with Indicator)

OTHER FITTINGS

EXTERNAL IN Jack

OUTPUT Jacks with Selector (HIGH/LOW)

Headphone Jack

FOOT CONTROLLER Jack

FOOT SWITCH Jack

Carrying Straps

Metal Corners

Slip Fittings

Power Cord Storage Space

OUTPUT SPECIFICATIONS

Nominal Levels

High: 0 dBm (800 mVrms)

Low: -20 dBm (80 mVrms)

Headphones: -10 dBm (250 mVrms)

Nominal Impedance

Output Jacks: 600 ohms

Headphone Jack: 8 ohms

CIRCUITRY

Solid State

Power Consumption: 180 Watts

Power Source: AC. 50/60 Hz

DIMENSIONS (W x H x D)

Assembled: 1,205 x 945 x 702 mm (47-1/2 x 37-1/4 x 27-5/8")

In Case: 1,205 x 290 x 702 mm (47-1/2 x 11-3/8 x 27-5/8")

Height to Keyboard: 842 mm (33-1/8")

WEIGHT

100 kg (220.5 lbs) Including Standard Accessories

FINISH

Black Leatherette with Walnut Veneer Panel Siding

STANDARD ACCESSORIES

Removable Cover

Vinyl Carrying Bag

Foot Controller (Expression Pedal)


Foot Switch Pedal

Music Rest

Detachable Casters


Specification subject to change without notice.

PANEL LAYOUT




1) CIRCUIT BOARD AND WIRING

The coding system is as follows



Two (2) black wires are connected to "E" on M circuit board. One goes to each "E" terminal of A and FG boards.



3) Transistor and FET



1) ABBREVIATIONS OF WIRE COLOR IN ELECTONE

BL	BLACK	BR	BROWN	RE	RED	OR	ORANGE
YE	YELLOW	GR	GREEN	BE	BLUE	VI	VIOLET
GY	GRAY	WH	WHITE	GG	GRASS GREEN	SB	SKY BLUE
PK	PINK	TR	TRANSPARENT	TP	TIN PLATED WIRE		


5) WIRE COLOR – Musical Note indication

C	C#	D	D#	E	F	F#	G	G#	A	A#	B
CR	RE	OR	YE	GR	BE	VI	GY	WH	GG	SB	PK

6) Logic Mark

FUNCTION	LOGIC MARK	
	HL	YAMAPA
SPACE (UNDEFINED)		
NOH		
HAHO		

KAS Circuit Diagram





KEY CODER & KEY ASSIGNER LSI (YM26600)


The LSI detects what keys are held down by judging the pulse combination of the octave and note. It also generates the seven bit key code, which is processed by time sharing, in accordance with the key held down.

- Pin. Pin
No. Name
- VSS +8.5V Power Supply
 - ϕ Master Clock Input
 - SC Synchro-clock Output
 - SC8 Synchro-clock Output on the first channel.
-
- IC Initial Clear Input
-
- VDD -6.5V Power Supply Input
 - CL Note on data input
 - C# Note on data input
-
- C Note on data input
-
- V1 Octave on data input
 - V5 Octave on data input
-
- N1 Note code data output
 - N4 Note code data output
- 1: -6.5V 0: +8.5V
- | | C# | D | D# | E | F | F# | G | G# | A | A# | B | C |
|----|----|---|----|---|---|----|---|----|---|----|---|---|
| N1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 0 | 1 |
| N2 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 0 |
| N3 | 1 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 0 |
| N4 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 |
- B1 Octave Code Data Output
 - B3 Octave Code Data Output
- 1: -6.5V 0: +8.5V
- | | C2 | C2#~C3 | C3#~C4 | C4#~C5 | C5#~C6 |
|----|----|--------|--------|--------|--------|
| B1 | 0 | 1 | 0 | 1 | 0 |
| B2 | 1 | 0 | 0 | 1 | 1 |
| B3 | 1 | 1 | 1 | 0 | 0 |
- KO1 Key on Data Output
 - KO8 Key on Data Output
-
- The number of note sounded is variable by using this pin.
i.e.) Up to 4 notes: Supply -6.5V to KO5.
Up to 3 notes: Supply -6.5V to KO4.
- Mode Switching output for sound model
For 8 notes Supply -6.5V (1)
For 7 notes Supply +8.5V (0)

D-A CONVERTER LSI (YM26700)

The time shared key data is supplied to the LSI. Analog DC voltage is produced in corporation with key by the data and supplied to each channel.

- VSS +8.5V Power Supply
- SC8 Synchro-clock input on the first channel.
- POR Portamento and Glissando operation. When the portament VR is turned on, +8.5V is supplied to the pin and actuate.
- PC Clock input for Portament and Glissando operation.



The frequency is variable by Changing the portamento VR.

- N1 Note code data input
Note code data is supplied to the pins from key coder LSI.
 - N4 Note code data input
Note code data is supplied to the pins from key coder LSI.
 - B1 Octave code data input
Octave code data is supplied to the pins from key coder LSI.
 - B3 Octave code data input
Octave code data is supplied to the pins from key coder LSI.
 - OO Output for octave key voltage. (8ch time sharing)
Provided the output key voltage for the octave selected from octave code.
 - OCT0 Input for octave key voltage.
 - OCT5 Input for octave key voltage.
- * TU pin: 4.0V

	OCT0	OCT1	OCT2	OCT3	OCT4	OCT5
Voltage	0.25V	0.5V	1.0V	2.0V	4.0V	4.0V

The voltage of TU line is divided by the ladder composed resistors and supplied to each pin constantly.

- C# Input for note key voltage
- C Input for note key voltage

OO pin: 4.0V


	C#	D	D#	E	F	F#
Voltage	2.119	2.245	2.378	2.520	2.670	2.828

	G	G#	A	A#	B	C
Voltage	2.997	3.175	3.364	3.564	3.775	4.0V



The voltage of OO line is divided by the ladder composed resistors and supplied to each pin constantly.

- CH8 Key voltage output
The output of voltage determined by each key is provided in accordance with the channel key code.
- CH1 Key voltage output
The output of voltage determined by each key is provided in accordance with the channel key code.
- VDD -6.5V Power Supply, Input
- ϕ Master Clock Input $f=94\pm 5\text{KHz}$


SH Circuit Diagram



Note) 1. IC5~IC12 :CA4016P




SH Circuit Board & Wiring




- Note) 1. ※ Mark : Ceramic Capacitor 0.1
 2. Volume : 332H
 3. IC1,3 : TC4011P
 IC2,4 : TC4016P
 IC5~12 : CA3140T
 4. Print Board #22544

TKC Circuit Diagram




TKC Circuit Board & Wiring



Note) 1. Print Board : LC21053
 2. IC 1, 2 : TC4019P
 IC 3 ~ 6, 19 : TC4013P
 IC 7 : TC4081P
 IC 8 ~ 10, 29, 30 : TC4068P
 IC 11 ~ 13 : TC4011P
 IC 14, 15, 21, 22, 28 : TC4073P
 IC 18 : TC4015P
 IC 20 : TC4071P
 IC 23 ~ 27 : TC4016P
 3. Camber-stop Hardware : #03892


TSB 1 Circuit Diagram



TSB 1 Circuit Board & Wiring

K-M2-E1	GR	(36') 113
K-T2-E1	GR	(37') 115
K-T3-F#1	VI	(38') 120
K-M2-F1	BE	(39') 116
K-T2-F1	BE	(40') 118
K-M2-A#1	SB	(42') 131
K-T2-A#1	SB	(43') 133
K-T3-C2	BR	(44') 202
K-M2-C1	BR	(45') 101
K-T2-C1	BR	(46') 103
K-T3-B1	PK	(47') 135
K-M2-E2	GR	(50') 213
K-T2-E2	GR	(51') 215
K-T3-F#2	VI	(52') 220
K-M2-F2	BE	(53') 216
K-T2-F2	BE	(54') 218
K-M2-A#2	SB	(56') 231
K-T2-A#2	SB	(57') 233
K-T3-C3	BR	(58') 302
K-M2-B2	PK	(59') 234
K-T2-B2	PK	(60') 236
K-M2-E3	GR	(62') 313
K-T2-E3	GR	(63') 315
K-T3-F#3	VI	(64') 320
K-M2-F3	BE	(65') 316
K-T2-F3	BE	(66') 318
		(68') +8.5
		(69') -6.5

K-T3-E1	GR	(37) 114
K-M2-F#1	VI	(38) 119
K-T2-F#1	VI	(39) 121
K-T3-F1	BE	(40) 117
	BR	(41) E
RA2-TKC-S11(27)		(42) S11
K-T3-A#1	SB	(43) 132
K-M2-C2	BR	(44) 201
K-T2-C2	BR	(45) 203
K-T3-C1	BR	(46) 102
K-M2-B1	PK	(47) 134
K-T2-B1	PK	(48) 136
	RE	(49) E
RA2-TKC-S12(27)		(50) S12
K-T3-E2	GR	(51) 214
K-M2-F#2	VI	(52) 219
K-T2-F#2	VI	(53) 221
K-T3-F2	BE	(54) 217
	OR	(55) E
RA2-TKC-S21(28)		(56) S21
K-T3-A#2	SB	(57) 232
K-M2-C3	BR	(58) 301
K-T2-C3	BR	(59) 303
K-T3-B2	PK	(60) 235
	YE	(61) E
RA2-TKC-S22(28)		(62) S22
K-T3-E3	GR	(63) 314
K-M2-F#3	VI	(64) 319
K-T2-F#3	VI	(65) 321
K-T3-F3	BE	(66) 317
	GR	(67) E
RA2-TKC-S31(26)		(68) S31
RA2-TKC-F#5(38)	PK12x2	(69) +8.5
RA2-TS82-F#5(69)	GG12x2	(70) -6.5
RA2-TS82-6.5(70)		




BL12x2	RA2-TKC-E(3)		
YE	K-M2-D#1		
YE	K-T2-D#1		
OR	K-T3-D1		
RE	K-M2-C#1		
RE	K-T2-C#1		
RE	RA2-TKC-B12(20)		
BR	RA2-TKC-B11(20)		
GG	K-T3-A1		
WH	K-M2-G#1		
WH	K-T2-G#1		
GY	K-T3-G1		
YE	K-M2-D#2		
YE	K-T2-D#2		
OR	K-T3-D2		
RE	K-M2-C#2		
RE	K-T2-C#2		
OR	RA2-TKC-B21(21)		
YE	RA2-TKC-B22(22)		
GR	RA2-TKC-B31(22)		
GG	K-T3-A2		
WH	K-M2-G#2		
WH	K-T2-G#2		
GY	K-T3-G2		
YE	K-M2-D#3		
YE	K-T2-D#3		
OR	K-T3-D3		
RE	K-M2-C#3		
RE	K-T2-C#3		
BR12x2	RA2-SH-A16(70)		
	RA2-TS82-F15(34)		


Note) 1. Print Board
2. Diode
3. ▲ Mark
4. IC 1 ~ 5
IC6 ~ 8

1. LC21191
2. IS1555
3. Tantalum Capacitor 0.33/35
4. Electrolytic Capacitor 1/25
IC 1 ~ 5
IC6 ~ 8

TSB 2 Circuit Diagram




TSB 2 Circuit Board & Wiring



Note) 1. Print Board
2. Diode
3. ▲ Mark
4. IC 1 ~ 5
IC 6 ~ 8

KBC 1 · 2 Circuit Diagram



D-A CONVERTER LSI (YM26700)

The time shared key data is supplied to the LSI. Analog DC voltage is produced in corporation with key by the data and supplied to each channel.

1. VSS +8.5V Power Supply
2. SCS Synchro-clock input on the first channel.
3. POR Portamento and Glissando operation. When the Portamento VR is turned on, +8.5V is supplied to the pin and actuate.
4. PC Clock input for Portamento and Glissando operation.



The frequency is variable by Changing the portamento VR.

5. N1 Note code data input
Note code data is supplied to the pins from key code LSI.
8. N2

9. B1 Octave code data input
Octave code data is supplied to the pins from key code LSI.
11. B2

12. OO Output for octave voltage. (8ch time sharing)
Provided the output key voltage for the octave selected from octave code.
13. OCT0 Input for octave key voltage.

* TU pin: 4.0V

	OCT0	OCT1	OCT2	OCT3	OCT4	OCT5
Voltage	0.25V	0.5V	1.0V	2.0V	4.0V	4.0V

The voltage of TU line is divided by the ladder composed resistors and supplied to each pin constantly.

19. C# Input for note key voltage
30. C

OO pin: 4.0V

	C#	D	D#	E	F	F#
Voltage	2.119	2.245	2.378	2.520	2.670	2.828


	G	G#	A	A#	B	C
Voltage	2.997	3.175	3.364	3.564	3.775	4.0V

The voltage of OO line is divided by the ladder composed resistors and supplied to each pin constantly.

31. CH8 Key voltage output
The output of voltage determined by each key is provided in accordance with the channel key code.
38. CH1

39. VDD -6.5V Power Supply, Input
40. φ Master Clock Input 1-9415KHz


KBC 1・2 Circuit Board & Wiring



- Note) 1. Print Board LC21216
2. Resistor 22K : ±5%
Other : ±1%
3. Diode 1S1555
4. VR1,2 (V10K4A-5-2)
5. IC1, 2 : CD4006AE
IC3 : TC4019P
IC4,5 : TC4013P
IC6,7 : TC4073P
IC8 : TC4069P
IC9,10 : TC4016P
IC11 : YM26700
IC12 : LM310
IC13~22 : NJM4558
6. Mark : Ceramic Capacitor
Other : Mylar Capacitor




TWS Circuit Board & Wiring




Note) 1. Print Board : LC21223
2. FET 1 ~ 8 : 2SK30
3. Diode 1 ~ 32 : 1S1555
4. IC 1 ~ 20 : NJM4558
5. ΔMark : Tantalum Capacitor

TRG 1-2 Circuit Diagram






TRG 3 Circuit Diagram




TRG 3 Circuit Board & Wiring




Note) 1. Print Board : LC21082
 2. IC 1 ~ 24 : IG00151
 3. Volume VR1 ~ 24 : 3 terminals (V10K8-1-2)

TRG 4 Circuit Diagram




TRG 4 Circuit Board & Wiring




Note) 1. Print Board : LC21091
2. IC 1 ~ 16 : IG00151
3. Volume VR1 ~ 16 : 3 terminals (V10K8-1-2)

TRG 5 Circuit Diagram




TRG 5 Circuit Board & Wiring




Note) 1. Print Board : LC21101
2. IC 1 ~ 17 : IG00151
3. Volume VR1 ~ 17 : 3 terminals (V10K8-1-2)
4. Diode : IS1555

BA Circuit Diagram




BA Circuit Board & Wiring



Note) 1. Print Board	: LC21063
2. Transistor	
FET 1, 2	: 2SK30
Tr 1 ~ 29	: 2SC468
3. Diode	: 1S1555
4. $\text{10k}\Omega$ Mark	: Metal Film Resistor (0.1%)
5. Volume	
VR1, 3, 4	: 3321H
VR2	: 3 terminals (V10K8-1,2)
IC	
IC 1	: TA7504
IC 2	: CA3140T (RCA)
IC 3 ~ 10	: NJM4558


SUB Circuit Diagram



SUB Circuit Board & Wiring

VCA IC (IG00151)

1. EI Input voltage for level control.
Input of the control voltage is provided for changing the level exponenten-
tially.




2. LI Input of level control voltage.
Input of the control voltage is provided for linear change of the level.



3. +IN Input
Input of the level modulated signal
is provided.




4. -IN Negative feed back.
Normally unused.
5. Vee -15V input power source.
6. Vcc +15V input power source.
7. GND Earth
8. OUT Output
- Output of the following wave shape is produced.



VCOII IC (IG00150)


1. VI Input of the control voltage.
The frequency is variable in accordance with the voltage supplied.




2. GND Earth
3. C Capacitor for determination of the frequency.
4. Vee -15V input power source.
5. Vcc +15V input power source.
6. SIO Output of sine wave.




8. Iadj Setting for standard electric current.
The standard electric current is set so as to be the output 200Hz when VC1 is 10V and VC2 is zero volt.



1. Print Board	LC20983	4. * Mark	2W Metal Oxide Resistor
2. Transistor	Tr6, 10, 14	5. Diode 1 ~ 22	IS1555
Tr1 ~ 5, 7, 11	2SA561	6. ZD	IS1715P
Tr8, 12	2SC828	7. Volume	
Tr9, 13	2SD234	VR 4, 5, 7 ~ 10 : 2 terminals (V10K4A-5-2)	
FET1, 2, 3	2SA490	VR 1 ~ 3, 6	3 terminals (V10K8-1-2)
	2SK30		
3. IC			
IC 2, 4, 8, 10	IG00151		
IC 5, 7, 9	IG00150		
IC 11	HA1462		
IC 1, 3, 6, 12, 13 : NJM4558			




T51 Circuit Board & Wiring




(96) F	BE	RA1-BA-16(9)
(95) E	GR	RA1-BA-15(8)
(94) D	YE	RA1-BA-14(7)
(93) C	OR	RA1-BA-13(6)
(92) B	RE	RA1-BA-12(5)
(91) A	BR	RA1-BA-11(4)

Note) 1. Print Board : LC22612
2. Diode : IS1555




TT52 Circuit Board & Wiring



Note) 1. Print Board : LC22621
2. Diode : IS1555
3. J : J10


(96) F	
	GR
(95) E	RA1-8A-I11(15)
	RE
(94) D	RA1-8A-I10(14)
	OR
(93) C	RA1-8A-I9(13)
	RE
(92) B	RA1-8A-I8(12)
	BR
(91) A	RA1-8A-I7(10)






Note) 1. Print Board : LC22612
2. Diode : IS1555

T54 Circuit Diagram




T54 Circuit Board & Wiring




(96) F		
(95) E	GR	RA1-BA111(48)
(94) D	YE	RA1-BA1110(47)
(93) C	OR	RA1-BA119(46)
(92) B	RE	RA1-BA118(45)
(91) A	BR	RA1-BA117(44)

Note) 1. Print Board
2. Diode
3. J : J10
: LC22621
: IS1555
: J10



M Circuit Diagram



	CS-80	CS-60,50
R1	10K	20K
R2	20K	40K
R3	40K	80K
R4	80K	160K
R5	100	180
VR4	B-500	B-1K
VR5	B-1K	B-2K
VR6	B-2K	B-5K

Note)

- Tr1~Tr5, Tr8: 2SC458
Tr6, Tr7: 2SA561
FET1~7: 2SK30
D: IS1555
- VR1: 3321H type
VR3: 3005 type
Other VR: V10K8-1-2 (3 terminals)
V10K4A-5-2 (2 terminals)
- Mark: Metal Film Resistor (2%)
K Mark: " (10%)
- IC: Ceramic Capacitor (1000P)

IC views show the pin disposition
looked from upper. (Opposite to Pattern)

- IC1~6: IC00151 (VCA)
IC7: TA7504M (VCOIII)
IC8: IC00153
IC9: IC00158
IC10, 11: IC00156
IC12: IC00152
IC13: IC00159

Constant value of R6, R7 in IC10, 11 according to rank

	CS80	CS50,60
A	2.7K	2.7K
B	2.2K	2.2K
C	1.8K	1.8K
A	3.3K	3.0K
B	2.7K	2.4K
C	2.2K	2.0K

VCO III IC (IG00153)

This IC is used for voltage controlled oscillator. Many different frequencies are produced by the voltage supplied.

1. FT Resistor for determination of the feet. The electric current is provided to the pin from transposition changing circuit so that the octave can be determined.

2. KV Input of the key voltage. The input of the voltage is provided to the pin in corporation with the keys held down.

High voltage High frequency
Low voltage Low frequency

Input Voltage	Output Frequency
0.250V	130.8Hz (C2)
0.500V	261.6Hz (C3)
1.000V	523.2Hz (C4)
2.000V	1046.0Hz (C5)
4.000V	2093.0Hz (C6)

Transposition "normal"


3. OFF-SET Zero adjustment of input buffer circuit
4. Vref -15V input power source.
5. Com Phase compensation for input buffer amplifier.
Normally, the output (KV + 1V) is supplied to the pin.
7. OUT Output



As to the frequency, refer to the Pin No.2 (KV).

8. GND Earth
9. Vref Input of the standard voltage.
10. CT Circuit for time constant.

The following wave shape is produced.



11. RT Circuit for time constant.



Determines the discharging voltage level.

12. T1 Input for the comparator.

Input of the wave shape (N) is provided. from the pin no. 14 (TO).

13. Iref Input of the standard electronic current

14. TO Output from time constant circuit.

The following wave shape is produced.

15. VIB Input for vibrato control wave. Input of the control wave is provided by VCO lever of SUB-OSC.

16. Vcc +15V input power source.

WSC IC (IG00158)

1. Vcc +15V input power source
2. SIO Output of the sine wave



3. TO Output of triangular wave.



4. SL Input of slice level.

The input of the DC voltage is provided to the pin for determination of the inverting level which makes triangular wave from sawtooth wave.



Sawtooth wave

5. SO Output of the inverter wave
Output of inverted sawtooth wave is produced.



Inverted sawtooth wave

6. 2TO Output of double triangle wave
Double triangle wave is produced from triangle wave.



Double triangle wave

7. PO Output of pulse wave.

8. Vcc -15V input power source.

9. PI Input of pulse wave

Input of sawtooth wave is provided.

The Q control current sets the Q equal to 5, when VO is 0 volt.

10. PW0 Output of OP amplifier.

11. PW1 Input of OP amplifier.

Input of the voltage is provided for determination of the sensitivity of PWM lever so that the pulse width is changed.

12. 2TI Input of triangular wave for producing double triangular wave shape.

Input of triangular wave (TO) is provided for making double triangular wave shape.

13. SI Input of the pulse for producing inverted sawtooth wave.

Input of the sawtooth wave is provided from VCO III for producing inverted sawtooth wave shape.


14. TI Input of the wave is provided for producing triangular wave shape.

Input of the wave shape (N) is provided. from the pin no. 14 (TO).

15. VIB Input for vibrato control wave. Input of the control wave is provided by VCO lever of SUB-OSC.

16. Vcc +15V input power source.

15. ST1 Input of the wave for producing sine wave.



16. GND Earth

Input of the triangular wave (TO) is provided for producing sine wave.

17. Vcc +15V input power source.

18. Vref -15V input power source.

19. CT Circuit for time constant.

20. RT Circuit for time constant.

21. T1 Input for the comparator.

Input of the wave shape (N) is provided. from the pin no. 14 (TO).

22. Iref Input of the standard electronic current

23. TO Output from time constant circuit.

The following wave shape is produced.

24. VIB Input for vibrato control wave. Input of the control wave is provided by VCO lever of SUB-OSC.

25. Vcc +15V input power source.

VCF IC (IG00156)

1. AI Signal Input
Input signals from VCO and WSC are provided to this pin.

2. KV Key voltage input
In order to change the tone color according to the tone range of keyboard, the designated voltage of the key will be supplied to the pin. (0.25-4.0V)

3. IC Adjustment of the cut off frequency.
Set the control current of the cut off frequency.

4. VI Input of the cut off voltage.
Input voltage of cut off frequency is supplied to this pin so that the tone color can be changed. The center point of the cut off frequency can be also set.

When the VK is 0.25V and VI is 5V, the cut off frequency is set to just 1KHz.

5. Vcc +15V input power source
6. Q0 Q adjustment.
The Q control current sets the Q equal to 5, when VO is 0 volt.

7. VO Input of the voltage for Q control.
Q is variable according to the control voltage supplied.
When the control voltage is 0V (Max.), Q=5

When the control voltage is 10V (Min.), Q=0.5

8. GND Earth
9. FB Q feed back
This is the feed back output pin for the Q control by which the Q is determined.

10. LP Low-pass output
The output of lower frequencies are produced.

11. C2 C pin for determination of the cut off frequency.
12. Vcc -15V power source.
13. BP Band-pass output.
The output of intermediate frequencies are produced.

14. Vcc +15V input power source.

15. ST1 Input of the wave for producing sine wave.

16. GND Earth

17. Vcc +15V input power source.

18. Vref -15V input power source.

19. CT Circuit for time constant.

20. RT Circuit for time constant.

21. T1 Input for the comparator.

Input of the wave shape (N) is provided. from the pin no. 14 (TO).

22. Iref Input of the standard electronic current

23. TO Output from time constant circuit.

The following wave shape is produced.

24. VIB Input for vibrato control wave. Input of the control wave is provided by VCO lever of SUB-OSC.

25. Vcc +15V input power source.

VCF-EG IC (IG00152)

This IC generates envelope wave shape which is supplied to VCF and control the tone color.

1. NC Not connected
2. B1 Input of buffer amplifier.
3. OUT Output of buffer amplifier.

The buffer amplifier is built in for the purpose of matching impedance.

Output wave

AT Key-ON
IL Key-OFF

4. GND Earth
5. Vcc +15V input power source.
6. G1 Gate 1
7. G2 Gate 2

AT starting data

Key ON-OFF data

8. Vcc -15V input power source.
9. AT Input of buffer voltage for determination of the attack time.
Input of the voltage between zero V and 10V is provided and the attack time is controlled from 1 mS until 1S.

10. 1DT Input of buffer voltage for determination of the decay time.
Input of the voltage between zero V and 10V is provided and the first decay time is controlled from 10mS until 10 S.

11. C1 C pin for determination of the cut off frequency.
12. HP Hi-pass output
The output of higher frequencies are produced.

13. IN Input of feed back
The input signal for determination of cut off frequency.

14. Vcc +15V input power source.

15. ST1 Input of the wave for producing sine wave.

16. GND Earth

17. Vcc +15V input power source.

18. Vref -15V input power source.

19. CT Circuit for time constant.

20. RT Circuit for time constant.

21. T1 Input for the comparator.

Input of the wave shape (N) is provided. from the pin no. 14 (TO).

22. Iref Input of the standard electronic current

23. TO Output from time constant circuit.

The following wave shape is produced.

24. VIB Input for vibrato control wave. Input of the control wave is provided by VCO lever of SUB-OSC.

25. Vcc +15V input power source.

11. 2DT Input of buffer voltage for determination of the sustain level.
Normally fixed to zero(0) volt.

12. TC Output of the time control.
Output of DC voltage is produced so that each time of attack, 1DT and 2DT are controlled.

13. LC Output of level control.
The higher the voltage, the shorter the time and the lower the voltage the longer the time.

14. AL Input of buffer voltage for determination of attack level.
Input of the voltage between (0V~10V) is provided and the attack level is controlled from 0V until +5V.

15. SL Input of buffer voltage for determination of the sustain level.
Normally fixed to zero(0) volt.

16. IL Input of buffer voltage for determination of the initial level.
Input of the voltage between zero 0V and ten 10V is provided and the initial level is controlled from zero to minus 5 volt.

17. Vcc +15V input power source.

18. Vref -15V input power source.

19. CT Circuit for time constant.

20. RT Circuit for time constant.

21. T1 Input for the comparator.

Input of the wave shape (N) is provided. from the pin no. 14 (TO).

22. Iref Input of the standard electronic current

23. TO Output from time constant circuit.

The following wave shape is produced.

24. VIB Input for vibrato control wave. Input of the control wave is provided by VCO lever of SUB-OSC.

25. Vcc +15V input power source.

Pitch Adjustment

*Before carrying out pitch adjustment, be sure to stabilize electrical circuits of your synthesizer more than 10 minutes after power switch is turned on.

- Adjust the following variable resistors, when tuning knob on the panel is in the center position, so that the voltage of TU terminal is $+4V \pm 0.1\%$ between the terminals TU (67) and E on KAS circuit board.

	Circuit Board	VR No.
CS-50	SUB	VR11
CS-60	SUB	VR14
CS-80	BA	VR3
		B-200 Ω
		B-100K Ω
		B-100K Ω

*Make sure, all the levers on the panel are in "OFF" position.

- Short circuit terminals EK (19) and E (1)(2) on M circuit board when tone selector is set to "FLUTE" and transposition lever is in OCT-UP (2) on CS-80 (+15V, terminal V11 on M circuit board) position. Then, adjust VR1 (B-10K) on M circuit board so that the voltage of terminal Cp (5) is within $0V \pm 120\mu V$.

- With checking the output frequency from the 9th pin of C9 (WSC) on M circuit board, adjust the VR3 (B-5K) to have the certain highest note.

CS-50, 60	C7 to be $4186 \text{ Hz} \pm 1 \text{ cent}$ when C6 key is depressed.
CS-80	C8 to be $8372 \text{ Hz} \pm 1 \text{ cent}$ when C6 key is depressed.
In the same manner, set the lowest note by adjusting the VR2 (B-500) as follows.	
CS-60	C3 to be $261.6 \text{ Hz} \pm 1 \text{ cent}$ when C2 key is depressed.
CS-60	C2 to be $130.8 \text{ Hz} \pm 1 \text{ cent}$ when C1 key is depressed.
CS-80	C3 to be $261.6 \text{ Hz} \pm 1 \text{ cent}$ when C1 key is depressed.

Note:

- You can easily find out which M circuit board is corresponding to the key depressed by hearing the subtle change of the tone with hum modulation when you are adjusting VR2 on A M circuit board.

- The order the possible sounds when keys are depressed in turn is:

When keys are depressed at a time:

$① \rightarrow ② \rightarrow ③ \rightarrow ④ \rightarrow ⑤ \rightarrow ⑥ \rightarrow ⑦ \rightarrow ⑧ \rightarrow ①$

Therefore, when you adjust the M8 circuit board, depress the 8th key while 7th key is holding down, then release the 7th key. In this way, you can take out the sound of 8th key depressed.

- Adjust the following variable resistors, when transposition lever is in "NORMAL" ("4") on CS-80 position (+15V at terminal IV) as below.

CS-50, 60	VR4 (B-1K); C5 to be $2093 \text{ Hz} \pm 1 \text{ cent}$ when C6 key is depressed.
CS-80	VR4 (B-500); C7 to be $4186 \text{ Hz} \pm 1 \text{ cent}$ when C6 key is depressed.

- Adjust the following variable resistors, when transposition lever is in "1 OCT-DOWN" ("8") on CS-80 position (+15V at terminal II) as below.


CS-50, 60	VR5 (B-2K); C5 to be $1046 \text{ Hz} \pm 1 \text{ cent}$ when C6 key is depressed.
CS-80	VR5 (B-1K); C6 to be $2093 \text{ Hz} \pm 1 \text{ cent}$ when C6 key is depressed.

- Likewise, adjust the followings, when transposition lever is in "2 OCT-DOWN" ("16") on CS-80 position (+15V at terminal I) as below.

CS-50, 60	VR6 (B-5K); C4 to be $523.2 \text{ Hz} \pm 1 \text{ cent}$ when C6 key is depressed.
CS-80	VR6 (B-2K); C5 to be $1046.4 \text{ Hz} \pm 1 \text{ cent}$ when C6 key is depressed.

- Finally, adjust the generating circuit for tuning standard voltage, when A3 key is depressed, so that the output is 443 Hz .

	Circuit Board	VR No.
CS-50	SUB	VR11
CS-60	SUB	VR14
CS-80	BA	VR3
		B-200 Ω
		B-100 Ω
		B-100K Ω



M11 - 12 Circuit Board & Wiring

M12

RA1-R51-V2 (22)	RE	(36) V
RA2-SH-K1 (38)	WHx2	(37) K
RA1-M12-K (37)	YE12x2	(38) -15
RA1-M12-15 (38)	YE30	(39) -15
RA1-M13-15 (38)	ORx2	(40) PW
PU-9C1P-5	YE12	(41) PWM
RA1-M11-PW (40)	YE12	(42) E'
RA1-M11-PWM (41)	GGx2	(43) NI
RA1-M13-PWM (41)	GRx2	(44) G2
RA1-M11-N1 (43)	YE12	(45) G1
RA1-M11-G2 (44)	BE	(46) CP2
RA1-M13-G2 (44)		
RA1-M11-G1 (45)		
RA1-M13-G1 (45)		
RA1-M12-CP7 (53)		

RA1-R51-FH2 (76)	GY	(51) F1
RA1-R51-OH2 (11)	WH	(52) Q1
RA1-M12-CP2 (46)	BE	(53) CP7


RA1-R51-FL2 (77)	GG	(55) F2
RA1-M12-CP3 (29)	VI	(56) CP8
RA1-R51-QL2 (61)	SBx2	(57) Q2
RA1-M13-L (58)	PKx2	(58) IL
RA1-M11-AL (59)	ORx2	(59) AL
RA1-M13-AL (59)	REx2	(60) RF
RA1-M11-RF (60)	BRx2	(61) DF
RA1-M13-RF (61)	BRx2	(62) AF
RA1-M11-DF (61)	REx2	(63) TR
RA1-M13-DF (61)	WHx2	(64) SL
RA1-M11-AF (62)	WHx2	(65) RA
RA1-M13-AF (62)	VIx2	(66) DA
RA1-M11-T (63)	BEx2	(67) AA
RA1-M13-T (63)		(68) TP2
RA1-M11-SL (64)		
RA1-M13-SL (64)		
RA1-M11-RA (65)		
RA1-M13-RA (65)		
RA1-M11-DA (66)		
RA1-M13-DA (66)		
RA1-M11-AA (67)		
RA1-M13-AA (67)		

M11

RA1-R51-V1 (21')	BR	(36) V
RA2-SH-K1 (38)	WHx2	(47) K
RA1-SUB-K (37)	YE12x2	(38) -15
RA1-M12-15 (38)	YE30	(39) -15
RA2-KAS-15 (89)	ORx2	(40) PW
RA1-T52-3 (31)	YE12	(41) PWM
RA1-M12-PW (40)	GGx2	(42) E
RA1-SUB-P1 (48)	GRx2	(43) NI
RA1-M12-PWM (41)	YE12	(44) G2
RA1-SUBNO1 (39)	BE	(45) G1
RA1-M12-G1 (45)		(46) CP2
RA1-M11-CP7 (53)		

RA1-R51-FH1 (74)	VI	(51) F1
RA1-R51-OH1 (6)	GY	(52) Q1
RA1-M11-CP2 (46)	BE	(53) CP7

RA1-R51-FL1 (75)	WH	(55) F2
RA1-M11-CP3 (29)	VI	(56) CP8
RA1-R51-QL1 (51)	GG	(57) Q2
RA1-T52-11 (22)	SBx2	(58) IL
RA1-M12-L (58)	PKx2	(59) AL
RA1-T52-12 (21)	ORx2	(60) RF
RA1-SUB-RE (60)	REx2	(61) DF
RA1-M12-RF (60)	BRx2	(62) AF
RA1-T52-14 (18)	BRx2	(63) TR
RA1-M12-DF (61)	WHx2	(64) SL
RA1-T52-13 (19)	WHx2	(65) RA
RA1-M12-AF (62)	VIx2	(66) DA
RA1-T52-11 (21)	BEx2	(67) AA
RA1-M12-T (63)		(68) TP2
RA1-T52-20 (11)		
RA1-M12-SL (64)		
RA1-SUB-RAO (61)		
RA1-T52-19 (15)		
RA1-M12-DA (66)		
RA1-T52-18 (13)		
RA1-M12-AA (67)		



M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

E (1)	E (1)
E (2)	E (2)

M12

BL12x2	BL12x2
RA1-M11-E (1)	RA1-M11-E (1)
RA1-M13-E (1)	RA1-M13-E (1)

CP6 (5)	CP6 (5)
---------	---------

M11

BL12x2	BL12x2
RA1-T52-E (1)	RA1-T52-E (1)
RA1-M12-E (1)	RA1-M12-E (1)

- 45 -

M17-18 Circuit Board & Wiring

M17

RA1-R51-V7 (24')	VI	(36) V
RA2-SH-K8 (66)	WHx2	(37) K
RA1-M27-K (37)	YE12x2	(38) -15
RA1-M16-15 (38)		
RA1-M18-15 (38)		
PU-9C1P-4		(39) -15
RA1-M16-PW (40)	ORx2	(40) PW
RA1-M16-PW (40)	YEx2	(41) PWM
RA1-M16-PWM (41)		
RA1-M18-PWM (41)		
RA1-M16-NI (43)	GGx2	(42) E'
RA1-M18-NI (43)		
RA1-M16-G2 (44)	GRx2	(43) NI
RA1-M18-G2 (44)		
RA1-M16-G1 (45)	YEx2	(44) G2
RA1-M18-G1 (45)		
RA1-M16-G1 (45)	BE	(45) G1
RA1-M17-CP7 (53)		(46) CP2

BL12x2 RA1-M16-E (1)
RA1-M18-E (1)

E (1)
E (2)

CP6 (5)

RA1-R51-FH7 (83)	BR	(51) F1
RA1-R51-OH7 (91)	RE	(52) Q1
RA1-M17-CP2 (46)	BE	(53) CP7
RA1-R51-FL7 (84)	OR	(55) F2
RA1-M17-CP3 (29)	VI	(56) CP8
RA1-R51-OL7 (91')	YE	(57) Q2
RA1-M16-JL (58)	SBx2	(58) IL
RA1-M18-JL (58)	PKx2	(59) AL
RA1-M16-AL (59)	ORx2	(60) RF
RA1-M18-AL (59)	REx2	(61) DF
RA1-M16-DF (61)	BRx2	(62) AF
RA1-M18-DF (61)	VIx2	(63) TR
RA1-M16-AL (62)	GYx2	(64) SL
RA1-M18-AL (62)	WHx2	(65) RA
RA1-M16-SL (64)	VIx2	(66) DA
RA1-M18-SL (64)	BEx2	(67) AA
RA1-M16-AA (67)		(68) TP2

BRx2 RA1-M16-I (15)
REx2 RA1-M18-I (15)
YEx2 RA1-M16-II (16)
BEx2 RA1-M18-II (16)
BLx2 RA1-M16-IV (17)
RA1-M18-IV (17)
RA1-M16-VII (18)
RA1-M18-VII (18)
RA1-M16-EK (19)
RA1-M18-EK (19)

I (15)
II (16)
IV (17)
VII (18)
EK (19)

CP1 (21)
TP1 (22)

LP2 (24)

LP1 (27)
CP4 (28)

CP3 (29)

LC (31)
CP5 (32)

0 (33)
+15 (34)
+15 (35)

M18

RA1-R51-V8 (25)	GY	(36) V
RA2-SH-K8 (66)	WHx2	(37) K
RA1-M28-K (37)	YE12x2	(38) -15
RA1-M17-15 (38)		
RA1-M21-15 (38)	YE30	(39) -15
PU-9C1P-4	ORx2	(40) PW
RA1-M17-PW (40)	YE	(41) PWM
RA1-M18-CP7 (53)		
RA1-M17-NI (43)	GGx2	(42) E'
RA1-M18-NI (43)		
RA1-M17-G2 (44)	GRx2	(43) NI
RA1-M18-G2 (44)		
RA1-M17-G1 (45)	YEx2	(44) G2
RA1-M18-G1 (45)		
RA1-M17-G1 (45)	BE	(45) G1
RA1-M18-CP7 (53)		(46) CP2

BL12x2 RA1-M17-E (1)
RA1-M18-E (1)

E (1)
E (2)

CP6 (5)

RA1-R51-FH8 (36)	RE	(51) F1
RA1-R51-OH8 (82)	OR	(52) Q1
RA1-M18-CP2 (46)	BE	(53) CP7
RA1-R51-FL8 (37)	YE	(55) F2
RA1-M18-CP3 (29)	VI	(56) CP8
RA1-R51-OL8 (92')	GR	(57) Q2
RA1-M17-IL (58)	SBx2	(58) IL
RA1-M18-IL (58)	PKx2	(59) AL
RA1-M17-AL (59)	OR	(60) RF
RA1-M18-AL (59)	REx2	(61) DF
RA1-M17-DF (61)	BRx2	(62) AF
RA1-M18-DF (61)	VIx2	(63) TR
RA1-M17-SL (64)	GYx2	(64) SL
RA1-M18-SL (64)	WH	(65) RA
RA1-M17-RA (65)	VIx2	(66) DA
RA1-M18-RA (65)	BEx2	(67) AA
RA1-M17-DA (66)		(68) TH2

I (15)
II (16)
IV (17)
VII (18)
EK (19)

CP1 (21)
TP1 (22)

LP2 (24)

LP1 (27)
CP4 (28)

CP3 (29)

LC (31)
CP5 (32)

0 (33)
+15 (34)
+15 (35)

M 23-24 Circuit Board & Wiring

M23

RA1-R52-V3 (22)	OR	(36) V
RA1-M13-K (37)	WH	(37) K
RA1-M22-15 (38)	YE12x2	(38) -15
RA1-M24-15 (38)		
RA1-M22-PW (40)	ORx2	(39) -15
RA1-M23-PWM (41)	YEx2	(40) PW
RA1-M24-PWM (41)		(41) PWM
RA1-M22-NI (43)	SBx2	(42) E'
RA1-M24-NI (43)	GRx2	(43) NI
RA1-M22-G2 (44)		(44) G2
RA1-M23-G1 (45)	YEx2	(45) G1
RA1-M24-G1 (45)		
RA1-M23-CP7 (53)	BE	(46) CP2

BL12x2 — RA1-M22-E (1)
RA1-M24-E (1)

E (1)
E (2)

CP6 (5)

RA1-R52-FH3 (78)	WH	(51) F1
RA1-R52-OH3 (12)	GG	(52) Q1
RA1-M23-CP2 (46)	BE	(53) CP7
RA1-T52-FL3 (79)	SB	(55) F2
RA1-M23-CP3 (29)	VI	(56) CP8
RA1-R52-OL3 (11')	PK	(57) Q2
RA1-M22-IL (58)	SBx2	(58) IL
RA1-M22-AL (59)	PKx2	(59) AL
RA1-M22-RF (60)	ORx2	(60) RF
RA1-M22-DF (61)	REx2	(61) DF
RA1-M22-AF (62)	BRx2	(62) AF
RA1-M13-TR (63)	OR	(63) TR
RA1-M22-SL (64)	GYx2	(64) SL
RA1-M22-RA (65)	WHx2	(65) RA
RA1-M22-DA (66)	V1x2	(66) DA
RA1-M24-AA (67)	BEx2	(67) AA
		(68) TP2

BRx2 — RA1-M22-I (15)
REx2 — RA1-M24-I (16)
YEx2 — RA1-M24-IV (17)
BEx2 — RA1-M22-VIII (18)
BLx2 — RA1-M22-EK (19)

CP1 (21)
TP1 (22)
LP2 (24)

GRx2 — RA1-M22-LP2 (24)
RA1-M24-LP2 (24)

LP1 (27)
CP4 (28)

YEx2 — RA1-M22-LP1 (27)
RA1-M24-LP1 (27)

CP3 (29)
LC (31)

VI — RA1-M23-CP8 (56)
OR — RA1-R52-LC3 (97)

CP5 (32)
O (33)
+15 (34)
+15 (35)

WHx2 — RA1-M22-O (33)
BR12x2 — RA1-M22-+15 (34)
RA1-M24-+15 (34)

M24

RA1-R52-V4 (23)	YE	(36) V
RA1-M14-K (37)	WH	(37) K
RA1-M23-15 (38)	YE12x2	(38) -15
RA1-M25-15 (38)		
RA1-M23-PW (40)	ORx2	(39) -15
RA1-M23-PWM (41)	YEx2	(40) PW
RA1-M25-PWM (41)		(41) PWM
RA1-M23-NI (43)	SBx2	(42) E'
RA1-M25-NI (43)	GRx2	(43) NI
RA1-M23-G2 (44)		(44) G2
RA1-M23-G1 (45)	YEx2	(45) G1
RA1-M25-G1 (45)		
RA1-M24-CP7 (53)	BE	(46) CP2

BL12x2 — RA1-M23-E (1)
RA1-M25-E (1)

E (1)
E (2)

CP6 (5)

BRx2 — RA1-M23-I (15)
REx2 — RA1-M23-II (16)
YEx2 — RA1-M25-II (16)
BEx2 — RA1-M23-IV (17)
BLx2 — RA1-M25-VII (18)
RA1-M23-EK (19)

CP1 (21)
TP1 (22)

LP2 (24)

GRx2 — RA1-M23-LP2 (24)
RA1-M25-LP2 (24)

LP1 (27)
CP4 (28)

YEx2 — RA1-M23-LP1 (27)
RA1-M25-LP1 (27)

CP3 (29)
LC (31)

VI — RA1-M24-CP8 (56)
YE — RA1-R52-LC4 (96)

CP5 (32)
O (33)
+15 (34)
+15 (35)

WHx2 — RA1-M23-O (33)
BR12x2 — RA1-M23-+15 (34)
RA1-M25-+15 (34)

— 50 —

M 27-28 Circuit Board & Wiring

M27

RA1-M26-V7 (24)	VI	(36) V
RA1-M17-K (37)	WH	(37) K
RA1-M26-15 (39)	YE12x2	(38) -15
RA1-M28-15 (38)		(39) -15
RA1-M26-PW (40)	ORx2	(40) PW
RA1-M26-PWM (41)	YE x2	(41) PWM
RA1-M28-PWM (41)		(42) E'
RA1-M26-NI (43)	SBx2	(43) NI
RA1-M28-G2 (44)	GRx2	(44) G2
RA1-M26-G1 (45)	YE x2	(45) G1
RA1-M27-CP7 (53)	BE	(46) CP2

BL12x2 RA1-M26E (1)
RA1-M28E (1)

E (1)
E (2)

CP6 (5)

RA1-R52-FH7 (83)	BR	(51) F1
RA1-R52-QH7 (91)	RE	(52) Q1
RA1-M27-CP2 (46)	BE	(53) CP7
RA1-R52-FL7 (84)	OR	(55) F2
RA1-M27-CP3 (29)	VI	(56) CP8
RA1-R52-QL7 (91')	YE	(57) Q2
RA1-M26-IL (58)	SBx2	(58) IL
RA1-M26-AL (59)	PKx2	(59) AL
RA1-M26-RE (60)	ORx2	(60) RF
RA1-M26-DF (61)	REx2	(61) DF
RA1-M28-DF (61)	BRx2	(62) AF
RA1-M28-AF (62)	VI	(63) TR
RA1-M17-TR (63)	GYx2	(64) SL
RA1-M26-SL (64)	WHx2	(65) RA
RA1-M26-RA (65)	VIx2	(66) DA
RA1-M26-DA (66)	BE x2	(67) AA
RA1-M28-AA (67)		(68) TP2

BRx2 RA1-M26-I (15)
REx2 RA1-M28-I (16)
YEx2 RA1-M26-IV (17)
BEx2 RA1-M26-VII (18)
BLx2 RA1-M28-VII (18)
RA1-M28-EK (19)

I (15)
II (16)
IV (17)
VIII (18)
EK (19)

CP1 (21)
TP1 (22)
LP2 (24)
LP1 (27)
CP4 (28)
CP3 (29)
LC (31)
CP5 (32)
O (33)
+15 (34)
+15 (35)

M28

RA1-R52-V8 (26)	GY	(36) V
RA1-M18-K (37)	WH	(37) K
RA1-M27-15 (38)	YE12x2	(38) -15
RA1-M27-15 (31)		(39) -15
RA1-M27-PW (40)	ORx2	(40) PW
PN1-MBK-M4-VR3	YE	(41) PWM
RA1-M27-PWM (41)		(42) E'
RA1-M27-NI (43)	SB	(43) NI
RA1-M27-G2 (44)	GRx2	(44) G2
PN1-MBK-M4-SW2	YE x2	(45) G1
RA1-M27-G1 (45)		(46) CP2
PN1-MBK-M4-SW1	BE	
RA1-M28-CP7 (53)		

BL12x2 RA1-M27-E (1)
RA1-M27-E (1)

E (1)
E (2)

CP6 (5)

I (15)
II (16)
IV (17)
VIII (18)
EK (19)

CP1 (21)
TP1 (22)
LP2 (24)
LP1 (27)
CP4 (28)
CP3 (29)
LC (31)
CP5 (32)
O (33)
+15 (34)
+15 (35)

VCA IC (IG00151)

1. EI Input voltage for level control.
The input voltage is provided for setting the level exponentially.



2. LI Input of level control voltage.
Input of the control voltage is provided for linear change of the level.



3. +IN Input of the level modulated signal is provided.



4. -IN Negative feed back.
Normally unused.

5. Vcc -15V input power source.
6. GND Earth
7. GND Earth
8. OUT Output

Output of the following wave shape is produced.



For checking, connect the resistor of 10K~20K ohm as illustrated.

VCOIL IC (IG00150)

1. VI Input of the control voltage.
The frequency is variable in accordance with the voltage supplied.



2. GND Earth
3. C Capacitor for determination of the frequency

4. Vcc -15V input power source.
5. Vcc -15V input power source.
6. SIO Output of time wave.



7. SO Output of smooth wave

8. Iadj Setting for standard electric current.
The standard electric current is set at 1mA when the power supply voltage VCI is 10V and VCI2 is zero volt.

VCA-EG IC (IG00159)

This IC generates envelope wave shape which is supplied to VCA and control the tone volume.

1. IL Input of initial level.
Fixed to 0V

2. BI Input of buffer amplifier.
The buffer amplifier is built in for the purpose of matching impedances.

Output wave shape



4. GND Earth
5. Vcc +15V input power source.
6. G2 Gate 2
7. G2 Gate 2

KEY-ON
KEY-OFF

AT starting data

Key ON-OFF data

8. Vcc +15V input power source.
9. AT Input of buffer voltage for determination of release time.

Input of the voltage between zero V and 10V is provided and the attack time is controlled from 1 mS until 1S.

10. 1DT Input of buffer voltage for determination of decay time.
Input of the voltage between zero V and 10V is provided and the decay time is controlled from 10 m second until 10 second.

11. 2DT Input of buffer voltage for determination of release time.
Input of the voltage between zero V and 10V is provided and the time key-off and release is controlled from 10 mS until 10 S.

12. TC Output of time control.
Output of the DC voltage is provided so that the attack time of Attack, 1st Decay and 2nd Decay are controlled.

KEY-ON
KEY-OFF

1st DT
2nd DT

Time control voltage

The higher the voltage, the shorter the time and the lower the voltage, the longer the time.


13. LC Output of level control
Level control voltage




Output of the DC voltage for AL and SL control is provided.

The higher the voltage, the higher the level and the lower the voltage, the lower the level.


14. NC Not connected.
15. SL Input of buffer voltage for determination of sustain level.
Input of the voltage between zero V and 10V is provided so that the sustain level can be controlled.



16. NC Not connected.




VCA-EG IC (IG00159)




2. Transistor	: 2SC828	: HA145T
Tr 1, 2	: 2SK30A	: G00151
FET 1 ~ 6		: IG00159
3. IC		: MA796HC
IC 1 ~ 4, 7		: IG00150
IC 5		: IS1555
IC 6		
IC 7		
IC 8		
IC 9		
4. Diode		
5. Volume		

VR 3, 9, 10 : V10K8-1-2
VR 1, 2, 4~8, 11, 12 : V10K4A-5-2

KEP-NA03577-6Z




OE: Circuit Board & Wiring




Note) 1. Print Board : LC21244
 2. Transistor : 2SK30Y
 FET : IS1555
 3. Diode : HA1452D
 4. IC : IC 1, 2, 7 : IG00150
 IC 3, 5 : NJM4558
 IC 4, 6 : 2 terminals (V10K4A-5-2)
 5. VR

OE₂ Circuit Diagram




OE₂ Circuit Board & Wiring



(Note) 1. Print Board

2. IC	: LC21253
IC 1	: BA617
IC 2	: TC4049
IC 3, 5	: HA1452D
IC 4	: MN3001
IC 7 ~ 10	: IC00151
3. VR	: 2 terminals (V10K4A-5-2)
	: 3 terminals (V8K8A-1-2)

SVU Circuit Diagram




[Caution]







When you carry out inspection on Power Supply Unit, be sure to make complete connection of the connector or Short Circuit both +15 ↔ +15S and -15 ↔ -15S. Otherwise, the circuit can break with the power on.

[注意]


電源ユニットの点検などで、コネクターを取外したままで電源を入れますと回路を壊す恐れがありますのでコネクターを取付けたまま、又は+15 ↔ +15S、-15 ↔ -15Sをショートさせて点検を行なう線をお願いします。




Power Supply NP0018Z (Primary) Circuit Diagram



Panel 1 Circuit Diagram



Panel 1 (MBK) Circuit Diagram




The diagram is a complex electronic schematic for a radio receiver. It is organized into several functional sections:

- TONE SELECTOR:** Located at the top, it includes a series of resistors and capacitors for tone control, with labels like BA-1 through BA-10.
- MIXER:** The central section, featuring a variable capacitor (VR12) and various resistors for signal mixing.
- AMPLIFIER:** Includes a variable capacitor (VR13) and resistors for signal amplification.
- OSCILLATOR:** Located on the left side, it includes a variable capacitor (VR14) and resistors for frequency oscillation.
- TOUCH RESPONSE:** A section on the right side, featuring a variable capacitor (VR15) and resistors for touch response control.
- KEYBOARD CONTROL:** A section on the left side, featuring a variable capacitor (VR16) and resistors for keyboard control.
- VOLUME:** A section at the bottom, featuring a variable capacitor (VR17) and resistors for volume control.


The schematic is densely packed with components, including resistors, capacitors, and various integrated circuits, with labels for each component and its value.

Panel 2 (Tone Selector) Circuit Diagram





15) IC1~14 ; IG00157
D ; 1S1555
R ; 12 $\frac{1}{2}$ Ω SW

Panel 3 Circuit Diagram




Panel 5 (EJ, EXP, PFS) Circuit Diagram









CS-80 SYNTHESIZER BLOCK DIAGRAM




CS-80 SYNTHESIZER BLOCK DIAGRAM



— PULSE — AUDIO SIGNAL — LOW FREQUENCY MODULATION SIGNAL — DC CONTROL SIGNAL





CS-80 OVERALL CIRCUIT DIAGRAM

002617

